


3D Reconstruction from Multiple Views



I. 3D RECONSTRUCTION USING MULTIPLE VIEW IMAGES [60 POINTS]

- 1) Take pictures of a small object near a checkerboard. You should take at least 6 pictures from different view points. If you have a zoom camera, do not change the zoom when you take pictures. If you do not have a camera, come to vision center, I will set up a place for image capturing.
- 2) Calibrate your camera using the camera calibration toolbox at http://www.vision.caltech.edu/bouguetj/calib_doc/. You need to download the toolbox. Before using the functions in the toolbox, be sure to set the path in Matlab by issuing the command:

```
path(path, 'your_toolbox_path');
```

where `your_toolbox_path` is the directory of the camera toolbox. After calibrating your camera and saving the result, a file named as `Calib_Results.mat` will be stored in your current directory. Check the projection error. It should be less than 1 pixel.

- 3) Compute the camera matrix. You can compute the first camera matrix using

```
load('Calib_Results.mat');
kk = [fc(1) 0 cc(1); 0 fc(2) cc(2); 0 0 1];
P1 = kk*[Rc_1,Tc_1];
```

The second one is $P2 = kk*[Rc_2, Tc_2]$ and so on. Write your camera parameters and matrices in the report.

- 4) Compute your camera projective centers for each view and write them in your report. The first camera projective center is

```
C1 = inv(P1(1:3, 1:3)) * (-P1(:,4));
```

- 5) Choose two views. Write a program that accepts user clicks on the corresponding point pairs on the two images and plot the reconstructed 3D point clouds. Put the result on your report. You can use `ginput` to get user input. For instance, you can show one image in `figure(1)` and the other is in `figure(2)`. Use the following script to get user mouse click location:

```
figure(1);
[x1, y1] = ginput(1);
figure(2);
[x2, y2] = ginput(2);
```

Call the following Matlab function to reconstruct the 3D points:

```
function M = triangulate(P1, m1, P2, m2)
```

```
% TRIANGULATE computes the 3D point location using 2D camera views
% P1: camera matrix of the first camera.
% m1: pixel location (x1, y1) on the first view. Row vector.
% P2: camera matrix of the second camera
% m2: pixel location (x2, y2) on the second view. Row vector.
% M: the (x, y, z) coordinate of the reconstructed 3D point. Row vector.
```

```
% Camera one
C1 = inv(P1(1:3, 1:3)) * (-P1(:,4));
x0 = C1(1);
```

```

y0 = C1(2);
z0 = C1(3);
m1 = [m1'; 1];
M1 = pinv(P1) * m1;
x = M1(1)/M1(4);
y = M1(2)/M1(4);
z = M1(3)/M1(4);
a = x-x0;
b = y-y0;
c = z-z0;
% Camera Two
C2 = inv(P2(1:3, 1:3)) * (-P2(:,4));
x1 = C2(1);
y1 = C2(2);
z1 = C2(3);
m2 = [m2'; 1];
M2 = pinv(P2) * m2;
x = M2(1)/M2(4);
y = M2(2)/M2(4);
z = M2(3)/M2(4);
d = x-x1;
e = y-y1;
f = z-z1;
% Solve u and v
A = [a^2 + b^2 + c^2, -(a*d + e*b + f*c);...
      -(a*d + e*b + f*c), d^2 + e^2 + f^2];
v = [ (x1-x0)*a + (y1-y0)*b + (z1-z0)*c;...
      (x0-x1)*d + (y0-y1)*e + (z0-z1)*f];

r = inv(A) * v;
M = [x0+a*r(1) y0+b*r(1) z0+c*r(1)];

```

Show the 3D points in your report. It helps to use the same unit in 3 different axes:

```

plot3(points(:,1), points(:,2), points(:,3), '+');
set(gca, 'DataAspectRatio', [1 1 1]);

```

Here `points` contain the 3D points you reconstructed. Rotate the point cloud and see whether the reconstruction makes sense. You can also generate an interpolated surface using the following procedure. `x` and `y` are image points in either of the two views.

```

tri = delaunay(x(:,1), y(:,2));
trisurf(tri, points(:,1), points(:,2), points(:,3));
set(gca, 'DataAspectRatio', [1 1 1]);

```

II. BONUS QUESTION (50 POINTS)

Automatically find the corresponding points and use multiple pictures to reconstruct a real 3D cloud of the object.